

CARE & USE

SMARTBURNER™ POLISH



PRODUCT INFORMATION

- Helps clean and maintain the original matte black appearance of SmartBurner.
- Helps protect and restore the surface from rusting and spotting.
- Helps to maintain the performance of the burner.
- 20 oz
- Made in Germany.

SMARTBURNER CARE AND USE TIPS

ALWAYS ensure the burner is cool before attempting to clean it. NEVER immerse or soak the burner in water.

- **STEP 1:** Use mild dish soap, or a soft sponge with a green scrub page on one side, and warm/hot water when cleaning your SmartBurners. Clean the SmartBurner by rubbing firmly in a circular motion.
- **STEP 2:** Rinse the sponge thoroughly and wipe the SmartBurner plate to remove dirt and excess soap.
- **STEP 3:** Dry the damp SmartBurner plate with a paper towel or soft dry cloth. The SmartBurner surface is now clean and ready to use.

NOTE: The stainless-steel rings can easily be removed from the burner for cleaning.

See reverse side for application.



1.800.433.6026



NEVER LEAVE COOKING UNATTENDED



PioneeringTech.com
PROTECTING PEOPLE & PROPERTY

APPLICATION

SMARTBURNER™ POLISH

SUPPLIES REQUIRED

1. SmartBurner plates that have been pre-cleaned using mild dish soap and a damp sponge.
2. One container of SmartBurner Polish.
3. Fully functional stove or cooktop (2 burner or 4 burner) with fully functional Range Hood above stove (if available) and standard North American electrical service (240v or 208v, single phase).

PROCEDURE

1. Install SmartBurner plate(s) per product installation instructions.
2. Turn the Range hood fan on to its highest setting.
3. Turn the stove dial to medium/low for 30 seconds.
4. After thirty seconds apply a thin layer of SmartBurner Polish to the top of the SmartBurner plate. With the heat from the plate, the SmartBurner Polish should go on smoothly and will glisten slightly.
5. After the application of the SmartBurner Polish, turn the burner temperature to medium/high to allow the SmartBurner Polish to bake into the SmartBurner.
6. Smoke will be visible. It is safe.
7. The SmartBurner Polish will be baked in and the smoke will be completely gone after approximately 4 minutes on medium/high.
8. After the smoke is completely gone turn the burner plate OFF.
9. Let SmartBurner cool.
10. After SmartBurner is cool wipe the plate with a soft cloth to remove any excess residue.
11. Cool times will vary. It is always recommended to place your hand 2-3 inches above the SmartBurner to ensure the plate is safe to touch.



1.800.433.6026



NEVER LEAVE COOKING UNATTENDED



PioneeringTech.com
PROTECTING PEOPLE & PROPERTY